

| | |
|---------------------------|-------------------------|
| 1 LM480S-40206-02 | Bolt |
| 2 LM480S-40202-03 | washer |
| 3 LM460SMH-40231-01 | blade |
| 4 LM480S-40142-01-1 | blade holder |
| 5 LM480S-40205-01 | key |
| 6 6SQDD08-25D | Bolt |
| 7 LM460SMH-40006-01-1 | Steel deck |
| 8 LM510SMH-40342-02 | spring |
| 9 LM510SMH-40045-01 | height adjusting pole |
| 10 6NH-06D | Nut |
| 11 LM510SMH-40440-02 | Front wheel |
| 12 LM510SMH-40020-01 | front wheel cover |
| 13 LM510SMH-40020-02 | rear wheel cover |
| 14 LM510SMH-40440-05-2 | rear wheel |
| 15 LM460SMH-40000-RV145-S | ENGINE RATO RV145-S |
| 16 LM510SMH-40081-02 | spindle of rear cover |
| 17 LM480S-40201-03 | stop ring |
| 18 LM510SMH-40292-01 | supporter of handle |
| 19 LM510SMH-40342-03 | spring |
| 20 LM510SMH-40181-01 | rear cover |
| 21 LM410P-40087-03 | lower handle |
| 22 LM460S-40440-10-1 | brake cable |
| 23 LM480S-40440-06 | knob |
| 24 LM480S-40206-07 | screw |
| 25 LM480S-40206-06 | Bolt |
| 26 LM480S-40087-02 | upper handle |
| 27 LM480S-40087-02 | lower handle |
| 28 LM480S-40087-03 | driving lever |
| 29 LM480S-40343-01 | hook |
| 30 LM510SMH-40440-04 | bag |
| 31 LM4510SMH-40292-01 | bag frame |
| 32 LM480S-40206-05 | screw |
| 33 LM510SMH-40292-01 | supporter of handle |
| 34 6ND-08D | Nut |
| 35 6ND-06D | Nut |
| 36 LM480S-40181-02 | |
| 37 6SQDD06-12D | Bolt |
| 38 LM510SMH-40440-01 | front wheel axle |
| 39 LM480S-40334-01 | axle tube |
| 40 LM510SMH-40342-01 | spring |
| 41 LM410S-40334-01 | plastic axle-tube |
| 42 LM510SMH-40440-07 | rear wheel axle |
| 43 6SDD06-12D | Bolt |
| 44 LM410S-40331-01 | height adjusting handle |
| 45 LM510SMH-40440-07 | height adjusting bar |
| 46 6NH-06D | Nut |