

NO.	BOM CODE	
1	6NG-06D	Cover nut
2	SG350-60185-01-1	mask
3	SG350-60440-14	Starter assembly
4	SG350-60185-02	Ventilation hood
5	6NG-12D	Hexagon head flange nut
6	SG350-60136-01	Passive plate
7	SG350-60403-01	fan
8	SG350-60206-05	Mask stud 2
9	SG475-60206-06	Mask stud 1
10	SG350-60609	flywheel
11	SG350-60342-01	Brake tension spring
12	SG350-60440-09	Brake assembly
13	6SQDD06-12D	Hexagon head flange bolt
14	6SQDD06-20D	Hexagon head flange bolt
15	SG350-60440-10	igniter
16	SG300-60208-03	Cylinder head gasket
17	SG575-60091-02	Cylinder head locating pin
18	SG475-60338-02	The exhaust valve
19	SG475-60338-01	Inlet valve
20	SG350-60206-03	Cross pan head screw
21	SG350-60182-03	Wind deflector 3
22	SG575-60611	The spark plug
23	SG350-60440-07	Cylinder head assembly
24	SG350-60206-06	stud
25	SG350-60208-05	Muffler insulation pad
26	SG350-60440-11	Muffler assembly
27	SG350-60440-12	Muffler cover assembly
28	6NE-06D	All gold locknut
29	SG350-60024-01	Cylinder head cover
30	SG350-60208-04	Cylinder head gasket
31	6SQDD08-45D	Cylinder head bolt
32	SG575-60207-02	nut
33	SG575-60207-01	Adjusting nut
34	SG350-60188-01	Valve rocker arm
35	SG575-60141-01	Intake valve spring seat
36	SG475-60342-01	Valve springs
37	SG575-60206-02	Valve rocker bolt
38	SG350-60181-02	Guide plate
39	SG350-60440-08	Valve push rod assembly
40	SG350-60440-00	Add pump
41	SG350-60200-01	Body oil seal
42	SG350-60310-01	The body bearing
43	SG300-60440-03	The crankshaft assembly
44	SG350-60440-06	The connecting rod assembly
45	SG300-60603-01	The piston
46	SG300-60053-03	ring
47	SG300-60053-04	Doctor blade ring
48	SG300-60053-02	Piston ring 2

49	SG300-60053-01	Piston ring 1
50	SG300-60054-01	Piston pin
51	SG300-60215-01	Piston pin retainer ring
52	SG350-60091-01	Case locating pin
53	SG350-60208-02	Body gasket
54	SG350-60440-02	Lid assembly
55	SG575-60202-01	Drain screw plug aluminum gasket
56	6SQDY10-15D	drain plug
57	6SQDD06-35D	Box cover bolts
58	SG475-60200-01	Lid seal
59	SG350-60440-13	Oil ruler assembly
60	SG350-60202-01	flat gasket
61	SG575-60202-02	Governing gear gasket
62	SG575-60186-01	Speed regulating gear single hole pressure
63	SG350-60081-01	Governor gear shaft
64	SG350-60440-05	Governor gear assembly
65	SG575-60202-03	Sliding sleeve gasket
66	SG350-60331-01	slide bushing
67	SG350-60440-04	camshaft
68	SG350-60087-02	lifter
69	SG350-60020-01-1	Air filter cover
70	SG350-60339-01	Empty filter core
71	6NG-06D	Hexagon head flange nut
72	SG350-60023-01	Small cover for air filter
73	SG350-60144-01-1	Air filter base
74	SG350-60440-13	carburetor assembly
75	SG350-60208-06	Carburetor gasket
76	SG350-60061-01	intake tube
77	SG575-60206-04	Carburetor bolt
78	SG350-60182-02	Wind deflector 2
79	SG350-60182-01	Wind deflector 1
80	SG350-60440-01	Housing assembly
81	SG350-60281-03	Tubing clamp 3
82	SG350-60087-01	oscillating bar
83	SG350-60061-02	flue gas leading
84	SG575-60200-02	Pendulum stem seal
85	SG575-60091-02	Swing rod spring cotter
86	SG350-60181-03	Speed regulating spring board
87	SG350-60043-01	The throttle push rod
88	SG475-60342-03	The gas spring
89	SG350-60342-03	governing spring
90	SG575-60206-03	Speed adjustment screw
91	SG350-60188-01	Speed rocker arm
92	SG350-60281-01	Tubing clamp 1
93	SG350-60061-03-1	pipeline
94	SG350-60281-02	Tubing clamp 2
95	SG575-60350-01	Oil spout strainer
96	SG350-60165-01-1	oilcan
97	SG575-60208-07	Tank cap gasket

98	SG575-60339-02	Tank cap sponge filter element
99	SG575-60020-02	can top
100	SG350-60292-02	Oil can support
101	SG350-60321-01	Breathing apparatus valve plate
102	SG350-60206-01	Breathing apparatus valve plate screw
103	SG350-60208-01	Respirator gasket
104	SG350-60181-04	Breathing apparatus cover plate

plate