




LM-C3805A part list

No.	Name	Qty
1	Cover handle	1
2	Bolt	8
3	Right cover washer	1
4	Right decorate cover	1
5	Filter	2
6	Impaction cap	2
7	Inner gear ring	1
8	Washer	1
9	motor	1
10	Motor pulley	1
11	Belt	1
12	Bearing clip	4
13	Wheel cover	2
14	Wheel cover beset	2
15	Wheel	2
16	Brake block	2
17	Brake pad	2
18	Pulley assembly	1
19	bearing	2
20	Brake spring	2
21	Male tab	2
22	Back wheel	2
23	bolt	9
24	Ring brake	1
25	Back wheel cover beset	2
26	Back wheel cover	2
27	Motor plate	1
28	Bearing	1
29	Circlip	1
30	Left decorate cover	1
31	Upper cover	1
32	Left cover washer	1
33	Bolt	19
34	Upper cover handle	1
35	Switchbox assembly	1
36	Wire clip	3
37	Bolt	2
38	knob	2
39	Nut	2

40	Hook	1
41	Lower push rod	1
42	Protection board spring	1
43	Protection board	1
44	Body	1
45	Set square	2
46	Move pole	1
47	Grass box	1
48	Rear wheel axes	1
49	Grass box cover	1
50	Grass box handle cover	1
51	Grass box handle	1
52	Grass full indicator plate	1
53	tongue	1
54	Bolt	2
55	Height adjustment cover	1
56	Shim	1
57	Height adjustment spring	1
58	Height adjustment handle	1
59	Body lower cover	1
60	Height adjustment axel	2
61	Height adjustment spring	1
62	Blade	1
63	Shim	1
64	Bolt	1
65	Washer	4
66	Front wheel axes	1
67	Block	1
68	Washer	1